



1. DIG A 4-5 INCH DEEP TRENCH ALONG EDGE OF LAWN.
2. PLACE EDGE EX EDGING INTO TRENCH. THE BOTTOM "V" LIP OF THE EDGING SHOULD BE FACING GROUND COVER OR PLANTING AREA.
3. POUND STAKE, PIERCING INTO EDGING AT A 45 DEGREE ANGLE. INSTALL STAKE EVERY 5' (CLOSER AT CURVES).
4. FOLLOW STEPS 4A - 4D TO CONNECT EDGING.
5. FILL BACK TRENCH AND TAMP DOWN.

STEPS FOR CONNETING EDGINGS TOGETHER

4A. CUT APPROXIMATELY 5 INCHES OFF THE ROUND TUBE FROM ONE OF THE EDGING.

CONNECTOR TUBING

4B. USE A CONNECTOR TUBING TO ALIGN BOTH ENDS OF EDGING.

4C. CONNECT THE TWO EDGING TOGETHER

4D. FOLLOW STEP "3" TO SECURE THE EDGING

PRODUCT NUMBER	NOMINAL DESCRIPTION	COLOR	ACTUAL DIMENSION D x H x L
100060052	20'	BLACK	1.12in X 5.2in X 20ft 2.84cm X 13.2cm x 6.09m

EDGE EX BLACK TUBE EDGING DETAIL-415 A

MADE IN USA by EPIC PLASTICS
 104 E. TURNER RD, LODI CA 95240
 www.epicplastics.com

209.333.6161

EDGE EX EDGING IS INTENDED FOR NON-STRUCTURAL USE ONLY